


# 3G Mobile Viewing Instruction Manual (For Android System)

## Chapter 1 Mobile Phone Setup

### Step 1



To install the “MobileView” software, please go into  to download the “Appsinstaller” program on your mobile phone first.



### STEP 2


Connect your mobile phone to your PC.

**NOTE:** In order to connect the mobile phone with PC, please install the USB driver which is included with the phone software CD. (Please refer to your mobile instruction manual)

### STEP 3


Copy the file “**MobileView.apk**” into your mobile phone.


### STEP 4



On your mobile phone, tap  → [Applications], and then enable “**Unknown sources**”


### STEP 5



Tap  to implement the installer system, and then click “**MobileView**” to start installing.

### Step 6




You will see the icon  after the successful installation.



# Chapter 2 3G Mobile Viewing Operation

## 2.1 Connect to DVR

### Step 1




Tap  to enter instant mobile viewing mode.

### Step 2

Enter the DVR information and click  to start connecting DVR.


For Example:



1. **IP / DDNS:** Set IP or DDNS address of the DVR you want to monitor.
2. **Port:** Set the Network port of the DVR you want to monitor.
3. **ID & Password:** Input LAN ID and password of the DVR you use.
4. **Keep me signed in:** You can enable this function to save the ID and password setting in your mobile.

**NOTE:** The ID & password are the LAN ID and password you selected; please refer to the instruction manual of your DVR.

## 2.2 3G Mobile Viewing Overview



### 1. Display Screen

MobileView program only provides single channel live viewing. Tap the display screen to switch to full screen, and tap the screen again to go back.



## 2. Channel Select

Select the channel you want to monitor.




## 3. Bitstream/ FPS

You can see the speed of network and frame per seconds.

## 4. Menu

**SETUP:** You can reset IP / DDNS, port, ID and password for your DVR. (Please refer to the section 2.1 Step 2)

**ABOUT:** You can see the version of MobileView program.



## 5. Exit Button

Click to exit mobile viewing mode.